



4.1.2.3 Sede maniglia costante - sicurezza



												
15												Nº
	601 – 800	690	200	263	N	J	N	N	– / –	– / –	Roto Sil	619591 ☒
	801 – 1000	890	200	413	N	J	N	N	1 / –	V / –	Roto Sil	626542 ☐
	1001 – 1200	1090	200	513	J	J	N	N	1 / –	V / –	Roto Sil	626543 ☒
	1201 – 1400	1290	200	563	J	J	N	N	1 / –	V / –	Roto Sil	626544 ☐
	1401 – 1600	1490	200	563	J	J	N	N	2 / –	V / –	Roto Sil	626575 ☐
	1601 – 1800	1690	200	563	J	J	N	N	2 / –	V / –	Roto Sil	626576 ☐
			200	1000	N	J	J	N	2 / –	V / –	Roto Sil	838324 ☐
	1801 – 2000	1890	200	1000	J	J	J	N	2 / –	V / –	Roto Sil	794641 ☒
	2001 – 2200	2090	200	1000	J	J	J	N	3 / –	V / –	Roto Sil	794642 ☒
	2201 – 2400	2290	200	1000	J	J	J	N	3 / –	V / –	Roto Sil	794643 ☒