





4.1.2.2 Sede maniglia costante



												N°
15	280 – 570	460	200	120	N	N	N	J	- / 1	- / P	Roto Sil	742199 <input type="checkbox"/>
	511 – 710		600	200	170	N	J	N	J	- / 1	- / P	Roto Sil
			200	170	N	J	N	N	1 / -	P / -	Roto Sil	795277 <input type="checkbox"/>
	601 – 800	690	200	263	N	J	N	N	- / -	- / -	Roto Sil	619591 <input type="checkbox"/>
	801 – 1000		890	200	413	N	J	N	N	- / -	- / -	Roto Sil
			200	413	N	J	N	N	1 / -	E / -	Roto Sil	619592 <input type="checkbox"/>
	1001 – 1200	1090	200	513	J	J	N	N	1 / -	E / -	Roto Sil	619593 <input type="checkbox"/>
	1201 – 1400		1290	200	563	J	J	N	N	1 / -	E / -	Roto Sil
	1401 – 1600	1490	200	563	J	J	N	N	2 / -	E / -	Roto Sil	619595 <input type="checkbox"/>
	1601 – 1800		1690	200	563	J	J	N	N	2 / -	E / -	Roto Sil
			200	1000	J	J	J	N	2 / -	E / -	Roto Sil	838345 <input type="checkbox"/>
	1801 – 2000	1890	200	1000	J	J	J	N	2 / -	E / -	Roto Sil	794637 <input type="checkbox"/>
2001 – 2200	2090		200	1000	J	J	J	N	2 / -	E / -	Roto Sil	795280 <input type="checkbox"/>
		200	1000	J	J	J	N	3 / -	E / -	Roto Sil	794638 <input type="checkbox"/>	
2201 – 2400	2290	200	1000	J	J	J	N	2 / -	E / -	Roto Sil	795282 <input type="checkbox"/>	
		2290	200	1000	J	J	J	N	3 / -	E / -	Roto Sil	794639 <input type="checkbox"/>



INFORMAZIONI

A partire da ABB 2401 mm, è necessaria una chiusura centrale.